

CD-BT2

Troubleshooting/FAQ

1	Even with batteries inserted and the power turned on, the screen display turns off quickly.	Are the batteries out of power? Try putting in new batteries.
2	The CD playback volume has become quieter than before.	Press the LEVEL key and check the CD LEVEL. Please refer to "Using a bass with the trainer" on page 30 of the Owner's Manual and adjust the CD playback volume.
3	Even when using the BEE CUT function, the bass sound is not reduced much.	If reverb and delay effects are used on the bass sound that you are trying to cancel, the BEE CUT function may not work well. Even if the bass sound is cancelled, the sound created by the effect may not be cancelled.
4	The bass volume is too low.	Is the INPUT dial turned up? Is the volume on the bass turned up? Press the LEVEL key and check the BASS LEVEL. If necessary, refer to "Using a bass with the trainer" on page 30 of the Owner's Manual and adjust the BASS volume.
5	There is no sound from the bass.	Is the bass cord connected? Is the INPUT dial turned up? Is the bass cord connected to the FOOT jack by mistake? Is the bass volume turned up? Press the LEVEL key to confirm the BASS LEVEL. If necessary, read "Using a bass with the trainer" on page 30 of the Owner's Manual and adjust the BASS level. Reconnect the cord to a bass amp or similar device to check if sound is produced. If all the above can be confirmed but there is still no sound through the unit, it could be broken. Please contact a TASCAM Service Center.
6	Can the bass effects be turned off?	Press the EFFECT key and set the BANK to "BYPASS" to turn the effects off. See "Using Built-in effects" on page 31 of the Owner's Manual.
7	Can the setting for effects and other functions be returned to the values that they had when shipped from the factory?	Press and hold the ◀◀ and ▶▶ keys simultaneously as you turn the power on to open the INITIALIZE screen at startup. Follow the instructions on screen after startup, and press the ▶/ key to restore every effect parameter, playback setting and other function to the default values that were set when the unit was purchased new.
8	The CD playback sound is uneven.	If you are using the unit's ability to change tempo without changing pitch or to change pitch without changing tempo, the CD sound undergoes special digital processing. This is not a malfunction.
9	CD playback is not possible, or a "DISC ERR" message is displayed and playback is stopped.	Are you using a disc that is non-standard, damaged, deformed or blank? Is this disc dirty? If the playback side (bottom) of the disc is dirty, wipe it clean with a soft cloth.
10	Can a CD-R/RW be played?	Playback is possible if a standard disc has been correctly recorded.
11	Can MP3s be played?	No, MP3s cannot be played.

1	電池を入れて電源を入れても、すぐに画面表示が消えてしまう。	消耗した電池を使用していませんか？ 新品の電池に交換してください。
2	CDの再生音が以前より小さくなった。	LEVELキーを押し、 CD LEVEL を確認してください。 取扱説明書28ページ「ベースを使う」をお読みいただき、CDの再生音量を調整してください。
3	BEE CUT機能を使ってもベースの音があまり消えない。	消そうとする音にリバーブやディレイといったエフェクトが使われている場合、 BEE CUT 機能がうまく働かない場合があります。中心となるベース音はキャンセルされますが、エフェクトの成分がキャンセルされずに残ってしまうためです。
4	ベースの音が小さい。	[INPUT]ダイヤルは上がっていますか？ ベースのボリュームは上がっていますか？ LEVELキーを押し、 BASS LEVEL を確認して下さい。必要に応じ、取扱説明書28ページ「ベースを使う」をお読みいただき、 BASS 音量を調整してください。
5	ベースの音が出ない。	ケーブルは接続されていますか？ [INPUT]ダイヤルは上がっていますか？ [FOOT]端子に接続していませんか？ ベースのボリュームは上がっていますか？ LEVELキーを押し、 BASS LEVEL を確認して下さい。 必要に応じ、取扱説明書28ページ「ベースを使う」をお読みいただき、 BASS 音量を調整してください。 接続しているケーブルをベースアンプなどに接続して音が出ることを確認して下さい。 以上のことを確認しても音が出ない場合は、本体の故障が考えられますので弊社修理センターにお問い合わせ下さい。
6	ベースのエフェクトをオフにすることはできますか？	EFFECTキーを押し、 BANK の設定を「 BYPASS 」にすることによりオフになります。 詳しくは取扱説明書29ページ「内蔵エフェクタを使う」をご確認ください。
7	エフェクトなどの設定内容を工場出荷時設定に戻すことはできますか？	◀◀、▶▶キーを同時に押しながら電源をオンすると、 INITIALIZE 画面が起動します。起動後、画面の指示に従い、▶/■キーを押すことにより、エフェクトパラメータ、各種設定などをお買い上げいただいた状態に戻すことができます。
8	CDの音がブルブル揺れたような音になる。	音程を変えずにテンポを変えたり、テンポを変えずに音程を変える機能を使用している時にCDの音に特殊なデジタル処理を行なっているため故障ではありません。
9	CD再生ができない、あるいは、メッセージ「DISC ERR」が表示され再生停止する。	規格外、傷、変形、未録音のディスクを使用していませんか？ ディスクが汚れていませんか？ 信号記録面が汚れている場合、柔らかい布で汚れを拭き取ってください。
10	CD-R/RWは再生できますか？	規格ディスクに正しく記録されている場合、再生可能です。
11	MP3は再生できますか？	再生できません。